

Your vehicle at a glance

Exterior overview.....	2-02
Interior overview.....	2-04
Instrument panel overview.....	2-05
Engine compartment.....	2-06

EXTERIOR OVERVIEW

■ Front view



1. Hood.....	p. 4-27
2. Head lamp (Features of your vehicle).....	p. 4-74
Head lamp (Maintenance).....	p. 8-85
3. Front fog lamp (Features of your vehicle).....	p. 4-77
Front fog lamp (Maintenance).....	p. 8-85
4. DRL lamp (Features of your vehicle).....	p. 4-77
DRL lamp (Maintenance).....	p. 8-85
5. Wheel and tire.....	p. 8-57
Wheel and tire.....	p. 9-06
6. Outside rearview mirror.....	p. 4-40
7. Sunroof.....	p. 4-32
8. Front windshield wiper blades (Features of your ve- hicle).....	p. 4-79
Front windshield wiper blades (Maintenance).....	p. 8-50
9. Windows.....	p. 4-22
10. Front radar.....	p. 6-50

■ Rear view




※ The actual shape may differ from the illustration.

OJA019002L

- | | |
|---|---------|
| 1. Door locks..... | p. 4-16 |
| 2. Fuel filler door..... | p. 4-29 |
| 3. Rear combination lamp (Maintenance)..... | p. 8-86 |
| 4. High mounted stop lamp (Maintenance)..... | p. 8-97 |
| 5. Tailgate..... | p. 4-20 |
| 6. Antenna..... | p. 5-02 |
| 7. Rear View Monitor..... | p. 4-72 |
| 8. Reverse Parking Distance Warning system..... | p. 4-69 |
| 9. Back up lamp (Maintenance)..... | p. 8-86 |
| Rear fog lamp (Maintenance)..... | p. 8-86 |
| 10. Rear window wiper blade (Features of your vehicle)
..... | p. 4-81 |
| Rear window wiper blade (Maintenance)..... | p. 8-51 |

INTERIOR OVERVIEW



* The actual shape may differ from the illustration.

OJA016003

1. Inside door handle.....	p. 4-17
2. Door lock/unlock button.....	p. 4-17
3. Outside rearview mirror folding switch.....	p. 4-42
4. Outside rearview mirror control switch.....	p. 4-41
5. Central door lock switch.....	p. 4-18
6. Power window lock button.....	p. 4-25
7. Power window switches.....	p. 4-22
8. Hood release lever.....	p. 4-27
9. Fuel filler door release lever.....	p. 4-29
10. Steering wheel.....	p. 4-36
11. Steering wheel tilt control.....	p. 4-37
12. Inner fuse panel.....	p. 8-68
13. Brake pedal.....	p. 6-29
14. Seat.....	p. 3-02
15. Headlight leveling device.....	p. 4-78
16. ESC OFF button.....	p. 6-34
17. TPMS SET switch.....	p. 7-08

INSTRUMENT PANEL OVERVIEW




OJA016004L


1. Instrument cluster..... p. 4-43
2. Horn..... p. 4-38
3. Driver's front air bag..... p. 3-49
4. Light control/Turn signals..... p. 4-74
5. Wiper/Washer..... p. 4-79
6. Ignition switch..... p. 6-06
ENGINE START/STOP button..... p. 6-10
7. Steering wheel audio control..... p. 5-11
8. LCD window control..... p. 4-44
Cruise Control (CC) switch..... p. 6-41
Manual Speed Limit Assist (MSLA) switch..... p. 6-47
9. Hazard warning flasher switch..... p. 7-02
10. Audio..... p. 5-06
11. Manual climate control system..... p. 4-87
Automatic climate control system..... p. 4-97
12. Cigarette lighter..... p. 4-114
13. AUX, USB port..... p. 5-03
14. Power outlet..... p. 4-118
15. Passenger's front air bag..... p. 3-49
16. Glove box..... p. 4-111
17. Shift lever M/T..... p. 6-20
Shift lever A/T..... p. 6-23
18. Seat warmer..... p. 4-116
19. Heated steering wheel switch..... p. 4-38
20. ISG (Idle Stop and Go) button..... p. 6-16
21. Center console storage..... p. 4-111
22. Cup holder..... p. 4-115

ENGINE COMPARTMENT

■ Kappa 1.0L MPI (Gasoline engine)



■ Kappa 1.2L MPI (Gasoline engine)




⚠ The actual engine room in the vehicle may differ from the illustration.

OJA076001/OJA076003B

- 1. Engine coolant reservoir..... p. 8-34
Engine coolant reservoir..... p. 8-37
- 2. Engine oil filler cap..... p. 8-33
- 3. Brake / clutch fluid reservoir..... p. 8-40
- 4. Air cleaner..... p. 8-46
Air cleaner..... p. 8-47
- 5. Fuse box..... p. 8-69
- 6. Negative battery terminal..... p. 8-53
- 7. Positive battery terminal..... p. 8-53
- 8. Engine oil dipstick..... p. 8-32
- 9. Radiator cap..... p. 8-34, 8-37
- 10. Windshield washer fluid reservoir..... p. 8-44
- 11. Automatic transmission fluid dipstick..... p. 8-42

■ Kappa 1.0L T-GDI (Gasoline engine)




- | | |
|--|---------------|
| 1. Engine coolant reservoir..... | p. 8-34 |
| Engine coolant reservoir..... | p. 8-37 |
| 2. Engine oil filler cap..... | p. 8-33 |
| 3. Brake / clutch fluid reservoir..... | p. 8-40 |
| 4. Air cleaner..... | p. 8-46 |
| Air cleaner..... | p. 8-47 |
| 5. Fuse box..... | p. 8-69 |
| 6. Negative battery terminal..... | p. 8-53 |
| 7. Positive battery terminal..... | p. 8-53 |
| 8. Engine oil dipstick..... | p. 8-32 |
| 9. Radiator cap..... | p. 8-34, 8-37 |
| 10. Windshield washer fluid reservoir..... | p. 8-44 |
| 11. Automatic transmission fluid dipstick..... | p. 8-42 |

* The actual engine room in the vehicle may differ from the illustration.

OJA077091B

■ Kappa 1.0L MPI (FFV engine)



- 1. Engine coolant reservoir..... p. 8-34
Engine coolant reservoir..... p. 8-37
- 2. Engine oil filler cap..... p. 8-33
- 3. Brake / clutch fluid reservoir..... p. 8-40
- 4. Air cleaner..... p. 8-46
Air cleaner..... p. 8-47
- 5. Fuse box..... p. 8-69
- 6. Negative battery terminal..... p. 8-53
- 7. Positive battery terminal..... p. 8-53
- 8. Engine oil dipstick..... p. 8-32
- 9. Radiator cap..... p. 8-34, 8-37
- 10. Windshield washer fluid reservoir..... p. 8-44
- 11. Automatic transmission fluid dipstick..... p. 8-42
- 12. Gasoline reservoir..... p. 4-30

* The actual engine room in the vehicle may differ from the illustration.

OJA077001B